




www.tuneyourengine.com

1989 - 1992 Toyota Supra ECU Diagram



Connector A

Pin #	Name	Signal Type
A11	Injector 2 & 6	Speed
A12	Injector 1 & 4	Speed
A25	Injector 3 & 5	Speed
A26	Power Ground	Ground

Connector B

Pin #	Name	Signal Type
B2	MAF Vortex	Analog
B3	Intake Air Temperature Sensor	Analog
B4	Engine Coolant Temperature Sensor	Analog
B6	Primary O2 Sensor Signal	Analog
B9	Sensor Ground	Ground
B11	Throttle Position Sensor	Analog

Connector D

Pin #	Name	Signal Type
D9	Vehicle Speed Sensor	Speed